




## BIOS Update Instruction

1. Please run the BIOS update file. (VGA\_BIOS\_Upgrade\_xxx.exe)
2. It will self-extract and then load the update module.


*(The screen may flash during the step.)*




3. It will pop up a message "Do you want to backup VGA BIOS to file?".  
(you can keep the old BIOS file if you need.)




4. If click "OK" please choose the save path.




5. Then another message pop up “Are you sure to update VGA BIOS?”.



6. Click “OK” to start the BIOS update.  
(The screen may flash during the step.)



7. Update completed. Please reboot the system to get the new BIOS to work.



8. Finish.